

Twin Pack Golf Driver

USER'S GUIDE



PACKAGE CONTENTS:

- (2) Wii Remote Handles
- (2) Golf Club Extensions
- User's Guide/Warranty Card
- Registration Card

HOW TO SET-UP THE WII REMOTE INTO THE WII REMOTE HANDLE:

1. Be sure that the Wii Remote is inside of the original Wii Remote Jacket.
2. Insert the Wii Remote with jacket into the Wii Remote Handle.

NOTE: You can insert the Wii Remote into the Wii Remote Handle with or without the Wii MotionPlus attachment.

3. Attach the elastic remote strap across the Wii Remote by placing the strap on the designated tabs located on both sides of the handle. The strap fits between the directional button and the A button on the Wii Remote.
4. To remove the Wii Remote from the Wii Remote Handle, detach the elastic strap from the tabs on both sides of the handle. Remove the Wii Remote from the handle.

NOTE: Use the IR Port on the Wii Remote Handle to navigate through the menus. The Wii Remote can remain inside the Golf Club Extension while navigating through the menus.

HOW TO SET-UP THE GOLF CLUB EXTENSION:

1. To attach the Wii Remote Handle to the Golf Club Extension, align the tabs located on the top of the cradle with the slots located on the bottom of the extension.
2. Insert the Golf Club Extension into the Wii Remote Handle.
3. Turn the Golf Club Extension counter-clockwise and lock into place.
4. To detach the Wii Remote Handle from the Golf Club Extension, slide down the latch located on the top of the Wii Remote Handle and turn the Golf Club Extension clockwise. Remove by lifting up and out.

NOTE: Always practice safety first. Be sure the Wii Remote is attached properly and securely to the extension. Be aware of your surroundings and stay a safe distance from all objects. **DO NOT** ever swing the Wii Remote at anyone or anything.

DISCLAIMER: dreamGEAR is NOT liable for any direct, indirect, punitive, incidental, special, consequential damages, or any damages whatsoever arising out of or connected with the use or misuse of this product.